

# QUICK START GUIDE

## 1- VaRoM INSTALLATION

To install the Valve Rotation Monitoring system on Valve Rotators, please follow the installation drawing “Mechanical Installation”.

## 2- SENSOR HUB INSTALLATION

Sensor Hub supports low range communication and can communicate with VaRoM on a special wireless network and transfers data to server via WiFi wireless protocol. Sensor hub shall be placed between 5 to 25 meters away from the cylinder head. **120-240V AC power socket is required.**

## 3- WIFI ROUTER INSTALLATION

WiFi Router can be installed far away from the sensor sub considering 2.4G Wifi protocol and signal interferences.

WiFi Router is a gateway to remote access via internet and to server for acquisition from sensor hub.

**LAN connection with internet access or 4G Modem connection is required.**

## 4- SERVER INSTALLATION

Server can be placed anywhere with a LAN cable connection to router.

